


M 440689916  
08/849875


463 T 301 S 2864830

— 1



08/849875

2/11

FIG 2

Synchronisation sequence - to allow modem to lock.	Message type.	Origination address of current hop.	Destination address of current hop	Final destination address of message.	Adaptation parameters-power, data rate, duration, duty cycle.	Origination address, message identifier and message data.	Error correction and detection codes
--	---------------	-------------------------------------	------------------------------------	---------------------------------------	---	---	--------------------------------------


FIG 5

Synchronisation sequence - to allow modem to lock.	Message type.	Origination address of current hop.	Destination address of current hop	Final destination address of message.	Adaptation parameters-power, data rate, duration, duty cycle.	Control parameters-probe, request acknowledgement message acknowledge.	Error correction and detection codes.
--	---------------	-------------------------------------	------------------------------------	---------------------------------------	---	--	---------------------------------------

FIG 6


M 4 0689916  
08/849875

3/II




08/849875

4/II




4(a)

5/11



M440689916  
08/849875

6/11




LESS 7

NET 30° S & 60°

08M44689975


7/11



M 440689916  
08/849875

8/11


E39 7



M 440689916  
08/849875

9/11

—E33 10




M 440689916  
087849875

10/11

LED 11

210


208



-087849875

12/11

SES /2



53 /3

